Installation instructions IP Weather Station WARIO ME13

WARIO inside







7



8



9



10



Caption / Components

1. 2pcs telescopic sections of the mounting pole
2. 1pc plastic mounting arm for the wind speed and wind direction sensor
3. 1pc wind direction sensor
4. 1pc wind speed sensor
5. 1pc rain gauge arm
6. 1pc rain gauge
7. 1pc box with the control unit, radiation shield for the combined sensors and metal arm
8. 1pc arm for attachment of the weather station to the console with a U screw
9. 5pcs connection screws
10. 2pcs installation clips for the console and telescopic part of the mounting pole
11. 4pcs tightening belts
12. 1pc power supply (PoE)
13. 2pcs LAN data cables